

# PRI Gateway

## User Manual



## Copy Right

Copyright © 2014 Allo. All rights reserved.

No part of this publication may be copied, distributed, transmitted, transcribed, stored in a retrieval system, or translated into any human or computer language without the prior written permission of Allo.com. This document has been prepared for use by professional and properly trained personnel, and the customer assumes full responsibility when using it.

## Proprietary Rights

The information in this document is Confidential to Allo and is legally privileged. The information and this document are intended solely for the addressee. Use of this document by anyone else for any other purpose is unauthorized. If you are not the intended recipient, any disclosure, copying, or distribution of this information is prohibited and unlawful.

## Disclaimer

Information in this document is subject to change without notice and should not be construed as a commitment on the part of **allo.com**. And does not assume any responsibility or make any warranty against errors. It may appear in this document and disclaims any implied warranty of merchantability or fitness for a particular purpose.

## About this manual

This manual describes the Allo product application and explains how to work and use its major features. It serves as a means to describe the user interface and how to use it to accomplish common tasks. This manual also describes the underlying assumptions and users make the underlying data model.

## Document Conventions

In this manual, certain words are represented in different fonts, typefaces, sizes, and weights. This highlighting is systematic; different words are represented in the same style to indicate their inclusion in a specific category. Additionally, this document has different strategies to draw User attention to certain pieces of information. In order of how critical the information is to your system, these items are marked as a note, tip, important, caution, or warning.

Icon	Purpose
	<b>Note</b>
	<b>Tip/Best Practice</b>
	<b>Important</b>
	<b>Caution</b>
	<b>Warning</b>

- **Bold** indicates the name of the menu items, options, dialog boxes, windows and functions.
- The color [blue](#) with underline is used to indicate cross-references and hyperlinks.
- Numbered Paragraphs - Numbered paragraphs are used to indicate tasks that need to be carried out. Text in paragraphs without numbering represents ordinary information.

- The Courier font indicates a command sequence, file type, URL, Folder/File name
- e.g. [www.allo.com](http://www.allo.com)

### **Support Information**

Every effort has been made to ensure the accuracy of the document. If you have comments, questions, or ideas regarding the document contact online support: <http://support.allo.com>

# Contents

## Table of Contents

About this manual.....	3
Document Conventions .....	3
Support Information .....	4
1.Product Introduction .....	8
1.1 Overview .....	8
1.2 Equipment Structure.....	9
1.2.1 Rear View .....	9
1.2.2 Front View.....	10
1.3 Functions and Features.....	11
1.3.1 Protocol Support.....	11
1.3.2 System Function.....	11
1.3.3 General Hardware Specification .....	11
2. Getting Started with PRI Gateway .....	13
2.1 Hardware Installation .....	13
2.2 Accessing the WEB GUI.....	14
3. Setting up Features .....	16
3.1 System Dash Board .....	16
Welcome Administrator.....	17
4. Setup .....	19
4.1 Trunks.....	19

4.1.1 SIP Trunks.....	19
4.1.2 PRI Trunks .....	23
4.2 Calling Groups .....	25
4.3 Call Routing Rules .....	27
4.3.1 Routing table.....	28
4.3.2 Manipulation table .....	31
4.4 Time-based Routing .....	34
5. Advanced Settings.....	37
5.1 ISDN PRI Settings.....	37
5.2 SIP Global Settings .....	39
6. System.....	41
6.1 Network .....	41
6.2 Date/Time .....	43
7. Tools.....	45
7.1 Diagnostics .....	45
7.2 Backup/Restore.....	46
7.3 Upgrade Firmware .....	47
8. Status .....	49
8.1 Call Reports .....	49
8.2 SIP Trunks.....	50
8.3 PRI Span .....	52
8.4 Current calls .....	53
8.5 Network .....	54

---

9. Frequently Asked Questions .....	55
10. Appendix .....	58
11. Appendix B: Glossary and Acronyms .....	59

# Introduction

## 1. Product Introduction

### 1.1 Overview

The aGP1/aGP2 is a PRI gateway aimed to target at small and medium offices and operators, and used to help enterprise to realize the evolution from the traditional PBX to voice IP. On the one hand, it supports PRI protocol and adopts standard T1/E1 trunk interface to realize docking with traditional PBX. On the other hand, adopt standard SIP protocol docking with various soft switches to ensure PSTN seamless access to IP voice network, and achieving VoIP. PRIGW100 supports intelligent multiple trunk routing technology, makes the operator easy to manage trunk routing by price optimum rule, and the automatic switch-over between multiple trunk routing makes the network have high reliability.

It has good call processing ability, and provides one or two T1/E1 interface. It is able to handle a variety voice decoding. It supports the rich GUI configuration, the user can easily set and maintenance the system. Mainly includes the following kinds of models:

aGP1 – 1 Span

aGP2 – 2 Spans

A typical network diagram shows the function of PRIGW100 as below.




Figure 1: Overview of Product

## 1.2 Equipment Structure

### 1.2.1 Rear View



Figure 2: Rear View

Interface	Description
Power	Connect the power adapter, 12VDC, 3.5A
PRI 1 & PRI 2	E1/T1 ports with line link LED indicators (Blue: Line normal)
WAN	Standard 10/100BASE-TX Ethernet Interface for WAN
Management Console (LAN)	Standard 10/100BASE-TX Ethernet Interface for LAN. Default Web GUI Login IP address is 192.168.113.2
Reset	Reset button for factory default.

### 1.2.2 Front View



Figure 3: Front View

### PRI Gateway Front Panel LED Indicators:

LED 8	LED 7	LED 2	WAN	LAN	Power
Blue On- PRI 1 link is up (No Alarm)	Blue On- PRI 2 link is up (No Alarm)	Blue On- System Ready Blue Blink- Factory Reset	Orange Blinks- WAN link is up.	Orange Blinks- LAN link is up.	Orange On- Power is on.

## 1.3 Functions and Features

### 1.3.1 Protocol Support

- Standard SIP V2 protocol
- E1/T1 PRI protocol
- NAT Traversing (STUN)
- Hypertext Transfer Protocol (HTTP)
- Domain Name System (DNS) & Dynamic host configuration protocol (DHCP)
- ITU-T G.711A-Law/U-Law, G.729AB, G.722

### 1.3.2 System Function

- Echo Cancellation: Up to 128msec echo tail length
- DTMF mode: RFC 2833, SIP INFO and INBAND
- Digit manipulation
- Integrated SIP registrar
- Early Media Support
- STUN support
- Call Detail Records (CDR)
- HTTP configuration
- Firmware upgrade by Web

### 1.3.3 General Hardware Specification

- Power supply: 12VDC, 3.5A

- Temperature: 0~40 deg(operational),-20~70 deg(storage)
- Humidity: 10%~90%, no condensation
- Max power consumption: 25W
- Dimension (mm): 250mm (W) x 220mm (L) x 43mm(H)
- Net Weight: 1.4 kg

## WARRANTY

### Hardware Warranty : 1 year

If the PRI Gateway was purchased from a Distributor/reseller, please contact the company where the device was purchased for replacement, repair or refund. If the device was purchased directly from Allo.com, contact our Technical Support Team for a RMA (Return Materials Authorization) number before the product is returned. Allo.com reserves the right to remedy warranty policy without prior notification.



Use the power adapter provided with the ALLO PRI Gateway. Do not use a different power adapter as this may damage the device. This type of damage is not covered under warranty.

# Getting Started

## 2. Getting Started with PRI Gateway



Figure 4: Getting Started with PRI Gateway

### 2.1 Hardware Installation

**Step 1:** Plug one end of the RJ45 Ethernet cable into your Router & other end into the WAN port of the PRI Gateway.



Use Straight-through Ethernet cable to connect between the unit & Router/Switch.

**Step 2:** Plug one end of the RJ45 cable into the PRI 1 port of the PRI Gateway & other end to the E1/T1 service provider socket.

**Step 3:** Insert the Power Adapter output connector into the “Power” port of the PRI Gateway & Plug in the Power Adapter to any available AC power outlet.

**Step 4:** The PRI Gateway will power up, and automatically connect itself to your network via DHCP (which you can later configure in the SETTINGS > Network Settings section)



Wait until the unit is completely booted up and make sure that LED2 is Blue.

## 2.2 Accessing the WEB GUI

PRI Gateway WEB GUI can be accessed either through WAN or Management Console. Steps to Access the GUI during the initial setup through Management Interface (LAN):

**Step 1:** Make the setup as described in Hardware setup section, Lets access the Web GUI through Management Interface (LAN)

**Step 2:** Change the Network setting of the PC in manual mode (i.e. Static IP mode). Assign the IP address to the PC in the range of 192.168.113.xxx (E.g:192.168.113.10), net mask as 255.255.255.0 and gateway & DNS as 192.168.113.1.

**Step 3:** Launch the web browser and enter the URL <http://192.168.113.2> (Default LAN IP address) to open the login page of PRI Gateway's Graphical Interface.



Figure 5: PRI Gateway Login Interface

**Step 4:** Login using the default username & password (Default: Username: admin; Password: admin). Successful login takes you to the Dashboard page. Observe the WAN IP address on the dashboard, this will be used to access the GUI from the WAN interface.



The Recommended web browser to access GUI is Mozilla Firefox.

**Step 5:** If your network is not enabled with DHCP server, configure the WAN port IP address manually in the **SETTINGS > Network Settings** section as per your requirement.

# Setting up Features

## 3. Setting up Features

Setting up your browser for working with PRI Gateway is simple. In order to run this application appropriately the following settings are to be configured.

### 3.1 System Dash Board

PRI Gateway Dash Board summarizes the gateway status with a graphical display. It provides detailed status of an individual entity is available under the Status Tab or it can be directly accessed.




Figure 6: System Dash Board



Please change the default administrator password to alphanumeric, to prevent hacking.

## Welcome Administrator



Figure 6: Administrator





Figure 7: Reboot the device

Reboot option helps you to reboot your device.

## Web Settings

Navigation through **Administrator** > change the **Web Settings**. Here you can change the administrator password.



The image shows a 'Web Settings' dialog box with a blue header and a close button (X) in the top right corner. The settings are organized into three sections:

- Web Session Timeout:** A text input field labeled 'Session Timeout' contains the value '3600', followed by '(seconds)' in smaller text.
- Default Filtering:** A dropdown menu labeled 'Entries per page' is set to 'All'.
- Change Password:** This section includes two radio buttons, 'Yes' (which is selected) and 'No'. Below them are three password input fields: 'Old Password', 'New Password', and 'Re-type Password', each containing five black dots to represent masked characters.

At the bottom right of the dialog, there are two buttons: a yellow 'SAVE' button and a grey 'CANCEL' button.

Figure 8: Web Settings

**Web Session Timeout :** Duration after which current web login session expires. Default: 3600 sec

**Default Filtering:** Number of entries in a table per page to be displayed.

**Change Password:** Modify Administrator password here.

Click on “**CHANGE PASSWORD**” button, followed by “**SAVE**” button to update the configuration changes.

# Setup

## 4. Setup

This section consists of all Trunks, calling groups, call routing rules and time based routing, it also explains all the description to be followed while creating a new process in the PRI Gateway.

### 4.1 Trunks

It helps to make the calls and bind between the two devices.

#### 4.1.1 SIP Trunks

It provides the interface to any SIP companion such as VoIP service provider, any SIP server or SIP clients. To add different types of interfaces, configure the signaling & media settings for each trunk.

#### Add a SIP Trunk

Navigation: **SETUP > SIP Trunk > Add a SIP Trunk**: This is where you setup your SIP Trunks

#### IP Peering



Figure 9: IP Peering

- Click Add SIP Trunk

- Create a SIP user account for below registration methods.

**Account Name** - Descriptive name for the SIP Trunk for user's reference.

**Username**- Username of endpoint (e.g.: IPPBX) will use to authenticate with the gateway.

**Registration Mode**- Whether the endpoint will register to this gateway or this gateway will register to the endpoint.

- a) None: No Registration, IP Address peering of the Gateway & Endpoint
- b) To Gateway: Endpoint (IPPBX or VoIP Service Provider) register with the Gateway
- c) From Gateway: Gateway register to the End point (IPPBX or the VoIP Service Provider)

- Enter the PBX or VoIP service provider IP address for registration mode “ From Gateway or None”
- Click authentication, if it is required

**Authentication**- Enable, if Authentication is required by the End point (VOIP Service Provider or IPPBX)

**Auth. Username**- It is used only for registration

**Password**- It is authenticating inbound or outbound registrations or calls.

**Proxy Address**- IP address or hostname with port of the endpoint (VOIP Service Provider or IPPBX) where the calls will be diverted. Default port no.: **5060**

**Outbound Proxy Address**- IP address or hostname with port of the outbound proxy server. This ensures that all the SIP packets are sent via specified proxy. Specifying the port is not mandatory. Default port no.: **5060**

e.g.: 192.168.0.222:5062 OR 192.168.0.222

- Click registration and add registrar address

**Register-** Enable, if Registration to the End point (VOIP Service Provider or IPPBX) is required.

**Registrar Address-** IP address or hostname with port of the Registrar server is register to gateway anywhere. Specifying the port is not mandatory. Default port no.: **5060**

e.g.: 192.168.0.222:5062 OR 192.168.0.222

**Bridge PIN-** You can set a PIN for outgoing calls on SIP trunk, thus you will set one more level of security. Leave it blank for unsecured mode.

- Create and Save All.




Figure 10: SIP trunk Type: From-Gateway

If you choose Registration mode- To gateway that shows available codec configurations.




Figure 11: SIP trunk Type: To-Gateway

### Advanced Options

**DTMF**- Set the default DTMF mode for sending DTMF digits. Options:

- INBAND – sent along with audio (requires 64 Kbit codec - alaw, ulaw)
- INFO – sent as SIP INFO messages
- RFC2833 – sent as RTP packets
- AUTO – System automatic selects the mode. Use RFC2833 if offered, inband otherwise.

Default: **AUTO**

**NAT** - Enable it, to address NAT-related issue for SIP & media sessions for this trunk.

You can enable/disable Features like NAT and set the DTMF method. You can also configure various Codec's and can also prioritize the active Codec's using the up and down arrows.



Configuring NAT settings under SIP Global Settings are required and Default: **disabled**

**Codec Configuration**- Choose the available Codecs and set priority in the order in which gateway should prefer to send and receive audio.

Supported codecs are alaw, ulaw, G.729, G.722



<input type="checkbox"/>	Account Name	Username	Registration	Options
<input type="checkbox"/>	jose	jose7282	None	 
<input type="checkbox"/>	IPPEER	1000	None	 
<input type="checkbox"/>	ELASTIXTRUNK	2000	To Gateway	 
<input type="checkbox"/>	3CXTRUNK	3000	From Gateway	 

Showing 1 to 4 of 4 entries

First Previous 1 Next Last

Add New Delete Selected

Figure 12: SIP Trunk Group Results



Make sure to click the **Save ALL** button in the top navigation bar, after adding/editing/deleting any Extension. This tab turns Orange if some changes are made and not saved.

#### 4.1.2 PRI Trunks

This will allow you to make calls using your PRI line. PRI Trunks provides the interface to any ISDN PRI companion such as PRI service provider or any other ISDN PBX. Create an interface for each span.

Navigate through **Setup > Trunks > PRI Trunks**

- Click on the **SETUP>> Trunks** link in the GUI, and then select Add new to create PRI Trunk.
- Enter your Trunk name (For example: Line 2) description and Out bound caller ID.
- Choose your allocate channels to the 1<sup>st</sup>/2<sup>nd</sup> port of the PRI Gateway.
- Click on “**Save**” button to update the configuration changes.




Figure 13: PRI Trunk Outgoing

**Span Name:** Select the appropriate PRI Spans.

**Trunk Name:** Descriptive name of the PRI Trunk for user's reference.

**Outbound Caller ID:** Configure the Caller ID Number that would be applied for outbound calls over this trunk.

**Bridge PIN:** You can set a PIN for outgoing call on PRI trunks, thus you can set one level of security. Leave it blank for unsecured mode.

**Call Direction:** In which way like incoming or outgoing the call is allowed through this PRI line.

**Channel Hunt group mode:** The sequence of checking the channels and we have four options But the default is **ascending sequential**.




Figure 14: Edit PRI Trunk

- Click **Save** button to save the information and details will be displayed on PRI Trunks.



Figure 15: PRI Trunk Summary

## 4.2 Calling Groups

A calling group allows a group of trunks to be addressed when creating a call routing rule. Multiple groups can be created with different combination of trunks, but of the same type (SIP & PRI).

**Setup > Trunks > Calling Groups**

This is where you can setup your Trunk calling Groups. You can create the Calling groups by selecting available trunks with two types: PRI trunk groups and SIP trunk groups.

**Group Name** : Descriptive name for the Calling Groups for user's reference.

**Group Type** : You can select group type as SIP or PRI Trunk. For e.g.: If you select Group Type as SIP, SIP trunks will be listed in available Table.

**Trunks** : Depending upon the Group Type you have selected, available trunks can be moved to "Selected" column, to be listed under this Calling Group.



Figure 16: Create Calling Group

- **Click on the Calling Groups** and then select Add New to create Calling group.
- Enter the Group name and Group Type.
- You can use the available Trunk s name which are include or exclude from the list.
- Click on **"Save"** button to update the Calling Group.



Click Edit button, you will be navigated to Edit calling group screen page. In this page you can edit the Group name and Group type.




Figure 17: Calling Group Results

- The Group Names that have been created are displayed.
- You have the options to select the Group name that you wish to Edit/Delete on screen.




Figure 18: Delete selected items

Click icon to delete the selected items.

### 4.3 Call Routing Rules

A call routing rule determines how a call is handled based upon certain characteristics such as dialed number, inbound trunk, DID, etc.

### 4.3.1 Routing table

Navigate through **Setup > Call Routing Rules> Routing Table**

To create Routing table enter the following details

**Name:** Descriptive name for the Call routing rule for user's reference.

**Description:** Provide the description for the Call routing rule. (Optional)

**Incoming Type:** Specify how the gateway should match incoming calls. The gateway can match on PRI Trunk, SIP Trunk or Calling Group.

**Incoming From:** Specify the available trunk or calling group for the selected Incoming Type.




Figure 19: Create Routing Table

- Click on “Save” button to update the configuration changes.

Here you can Create/Edit the Rule

**Input type:** It is used to make the incoming number based on the input type options. And also it's received the incoming call.

**Pattern:** Specify the pattern to match the dialed string of the incoming call and its applicable for input type.

**e.g.:** X. – match at least one digit

988XXXX – match 988 followed by 4 digits

**Manipulation table:** Here we can manipulate the called number to caller number and caller name etc

**Route type:** This route type will send the incoming calls to the destination and we have different types of destination. We have different route types like Trunk, TMRoute Group, and Routing table.




Figure 20: Create/Edit Rule- Trunk Route type

**Outbound call Route:** Select the preferred trunks or time route groups where calls are to be routed for this Routing rule.

- If we select Trunk Route type the outbound call rule will show the available PRI Trunks.
- If we select the TMRoute Group the outbound call route will appear available office timings.

Figure 21: Create/Edit Rule-TM Route Group

**Trunk Route Type:** It is a routing table and the user should create one more rule in the same table by using **Add** Button.

Figure 22: Create Routing Table- Route Type (Routing Table)



Please save or close this Rule for saving the Routing table.




Figure 23: Routing Table Result

### 4.3.2 Manipulation table

Here we can manipulate the called number to caller number and caller name etc.




Figure 24: Create Manipulation table

Click **ADD** button, the create/Edit Rule screen will be displayed.

To create Manipulation table, enter the following details

**Name:** Descriptive name for the Manipulate table for user's reference.

**Description:** It provides the description for the manipulation table. (Optional)

**Input Type:** It depending on the number you dial, the input type will select the called number.

**Output Type:** Select proper number where the destination calls are going.

Figure 25: Create /Edit Rule in manipulation table



Please save or close this rule for saving the Routing table.

**List of Rules**

**Pattern :**

X matches any digit from 0-9

Z matches any digit from 1-9

N matches any digit from 2-9

[1237-9] matches any digit or letter in the brackets

(in this example, 1, 2, 3, 7, 8, 9)

[a-z] matches any lower case letter

[A-Z] matches any UPPER case letter

. Wildcard, matches one or more characters

! Wildcard matches zero or more characters immediately.

### **Number of Digit Left/Right Strip:**

It allows the user to specify the number of digits that will be stripped from the dialed number. For an Example: If you configure the pattern as 9X. And you want to strip 9 then you should mention Left/Right strip Digits field as 1

**Prefix to Add:** It allows the user to specify the digits which are prefix before placing the call via trunk. Ex: If dialed number is 8789763010 and if you want to Prefix 44 as a country code then mention in prefix digits field as 44

### **Suffix to Add:**

It allows the user to specify the digits which are suffix after placing the call via trunk. Ex: If dialed number is 8789763010 and if you want to Suffix 44 as a extension code then mention in suffix digits field as 44

**Reserve Digit from Right:** It doesn't allow user to change the digit (its reserved).

**Create Manipulation Table**

Name:

Description:

Input Type:

Output Type:

List of Rules							<input type="button" value="+ ADD"/>
Input	Output						
Pattern	Left Strip	Right Strip	Prefix	Suffix	Reserve	Options	
X.	1	1	9	8			<input type="button" value="✎"/> <input type="button" value="✖"/>

Figure 26: List of Rules created

**Manipulation Table**

Show:  entries Search:

<input type="checkbox"/>	Table Name	Description	Rules	Options
<input type="checkbox"/>	MT1		Rules	<input type="button" value="✎"/> <input type="button" value="✖"/>
<input type="checkbox"/>	MT1	Manipulation table	Rules	<input type="button" value="✎"/> <input type="button" value="✖"/>

Showing 1 to 2 of 2 entries   1

Figure 27: Manipulation Table Result



Make sure all the configuration files are successfully updated.

### 4.4 Time-based Routing

Time based routing route calls to different locations based on the time of day and day of week, when a call is made.




Figure 28: Create Time-based Routing

Navigate through **Setup > Trunks > Time- based Routing**

- Click **Add New** to create a Time-based Routing Group
- Enter the Group Name and Description.

**Group Name:** Descriptive name for the Time-based Routing Group for user's reference.

**Description:** Provide the proper description for the Time based routing rule. (Optional)

**Route to Trunk:** Select the destination trunk where the call is routed to on matching the time. The destination can be any trunks – PRI Trunks/SIP Trunks.

**Duration:** Specify the time range for which this routing rule will apply. Format: hh:mm

**Days:** Select the day/days during which this routing rule will apply.



Make sure that the current date and time are configured correctly under **System> Date/Time Configuration**.

Click **Save** button to save the information and details will be displayed on Time based Routing.



Figure 29: Time Based Routing Groups Results

You can check the Group name that you have created and also search by mentioning the group names in the search tab.

An Edit  option is provided to either Edit or add the assigned rules in the time-based routing group.

Click delete  button to delete the Group Name.

# Advanced

## 5. Advanced Settings

This chapter consists of all the advanced settings. Some of the important settings of the PRI Gateway are explained below.

### 5.1 ISDN PRI Settings

In this section, you can view and configure ISDN settings for PRI Gateway

**Navigate** : **Advanced > ISDN PRI Settings**

This section provides the ability to modify the PRI settings depending on the carrier (T1/E1), signaling, switch type, etc with respect to the service provider or any other companion.




Figure 30: Advanced PRI Settings

**Span Type** : Select the carrier type, E-carrier (E1) or T-carrier (T1) which depended on lines provided in your country. Default: **E1**

**Enable Progress indication** : Enabling this will provided call progress tones. Required, if service provider fails to provide call progress tones.

- Click on **“SAVE”** button, to update the PRI settings.

In ISDN PRI Settings enter the following details

**Framing/coding** : Select Proper Framing & coding by checking with your service Provider. If CRC is enabled from Telco side, Please select CCS/HDB3/CRC4. If not select CCS/HDB3.

Default for E1: **CCS/HDB3**

Default for T1: **ESF/B8ZF**


**Signaling** : Select if gateway should work as customer premises equipment (CPE) or network device (NET). If Gateway is connecting to PRI service provider, select PRI-CPE. If connected with other Digital PBX's configured as CPE, then select PRI-NET.

Default: **PRI-CPE**

**Switch** : Select the switch type as indicated by the ISDN service provider. Default: **E1- Euro ISDN & T1- National ISDN2**

**Sync/Clock Source** : Specify a transmit clock source. Master clocking uses the device's own system clock. Primary or secondary clocking uses a signal received from the T1 or E1 interface.

Default: **Master**



ISDN PRI Settings ?

Show All entries Search:

No. ^	Span ^	Framing/Coding ^	Channels ^	Signaling ^	Switch ^	Clock ^	Alarm ^	Options
1	PRI1	ccs,hdb3,crc4	30/31(E1)	PRI-CPE	EuroISDN	Secondary		
2	PRI2	ccs,hdb3	30/31(E1)	PRI-CPE	EuroISDN	Master		

Showing 1 to 2 of 2 entries First Previous 1 Next Last

Advanced

Figure 31: ISDN PRI Settings Result

- The ISDN PRI Settings that have been created are displayed.
- You have the option to select the ISDN PRI Settings to edit and made changes on Screen.




Figure 32: Confirm Reboot

## 5.2 SIP Global Settings

Navigate through Advanced and select SIP Global Settings it's applied to all VoIP traffic.




Figure 33: SIP Global Settings

### Port Settings

- **SIP Bind Port:** Choose a port on which to listen for SIP UDP traffic. Default: **5060**

- **RTP Port Range:** Range of port numbers to be used for RTP traffic. Default: **16001- 17000** make sure you configure this dynamic range of ports on your NAT Router. When the PRI Gateway is behind a NAT and the NAT is configured to do port forwarding with above mentioned port range for UDP ports.

### NAT Settings

- **NAT:** NAT option is checked, when the PRI Gateway is behind the Router/Firewall. Select either Stun Server IP or External IP. Default: **disabled**
- **Stun Server IP:** If the PRI Gateway is behind a non-symmetric NAT router, it may be necessary to use STUN to allow PRI Gateway to reliably communicate via IP through the router. Enter a STUN server IP address or domain name in the STUN Server field. For a list of public STUN servers, please Refer to: <http://www.voip-info.org/wiki/view/STUN>
- **External IP:** Enter the NAT Traversal IP address i.e. Public IP Address of your internet, to communicate with Public Network when PRI Gateway is behind the NAT. This IP address will substitute in all outgoing SIP messages instead of Local IP address.
- **Local Net mask:** Entering the Net mask of the local network of the PRI gateway allows it to identify the hosts falling within the same network. E.g.: 192.168.2.0/255.255.255.0

### Registration Timer

- **Default Registration Expiry:** Default duration (in seconds) of incoming/outgoing registrations. Default: **120 sec**
- **Min Registration Expiry:** Minimum duration (in seconds) of registrations allowed by the Gateway. Default: **60 sec**
- **Maximum Registration Expiry:** Maximum duration (in seconds) of incoming registrations allowed by the Gateway. Default: **3600 sec**
- **Registration Timeout:** Registration attempt will be retried till this duration (in seconds), if no response from the Registrar. (Outbound Registrations only). Default: **20 sec**
- **Registration Attempts:** Number of registration attempts before giving up with registrar (Outbound Registrations only). Default: **0** (never give up)

# System

## 6. System


This section consists of Network, Date/time configuration settings of the PRI Gateway are explained below.

### 6.1 Network

The Network sub menu allows users to configure the LAN-side IP address and DHCP Server settings, as well as the WAN-side settings like IP address of the WAN port.

By clicking on the **SETUP > Network** link on the top navigation of the PRI Gateway menu, we reach this section:

#### Network Settings (Firmware Version 3. X.X)



WAN Configuration		LAN Configuration	
<input checked="" type="radio"/> DHCP Client <input type="radio"/> Static IP		IP Address: 192 . 168 . 113 . 1	
IP Address:	192 . 168 . 0 . 31		
Netmask:	255 . 255 . 255 . 0		
Gateway:	192 . 168 . 0 . 254		
DNS 1:	192.168.0.5		
DNS 2:	192.168.0.254		
		Host Configuration	
		Hostname:	192.168.0.31

Apply

Figure 34: Network Settings

**WAN Configuration:** Are the Internet settings of your PRI Gateway.

1. **DHCP:** when enabled and a DHCP server is available, the PRI Gateway will auto configure itself. If DHCP is not available, select "**Static**", and fill in the Network Configuration

2. IP Address: the IP address corresponding to your WAN configuration\*
3. Net mask: the Net mask corresponding to your WAN configuration\*
4. Gateway: the IP address corresponding to your Gateway\*
5. DNS 1: the IP address corresponding to a DNS server\*
6. DNS 2: the IP address corresponding to a DNS server\*



DHCP mode is not recommended WAN side. Or trouble may arise when SIP trunk (From Gateway) need to change registration server address caused by revised IP.

**LAN Configuration:**

Use this setting in the event that you want to use the PRI Gateway as your network router.

- **IP Address:** It is a Base IP Address of a LAN Port, which functions as a gateway for its LAN. Default value is 192.168.113.1 ( You can log in Web GUI through:192.168.113.2)

**Network Settings (Firmware Version 4. X.X)**




Figure 35: Network Settings



WAN port IP address and LAN port IP address should not be in the same network segment.

**Media Configuration:** 4. 0.0 version onwards, please refer 4.x.x Network Settings

**Media IP Address need to be configured manually and it should be in the same network segment of WAN IP address. This IP address is used for Voice Media Configuration.**

For E.g.: If the WAN IP address is 192.168.0.145 and media IP address should be in the same Network Segment (available IP address) side. 192.168.0.3



*If the media IP address is not configured, there won't be voice path in the calls.*




Figure 36: Conform



System will reboot to apply the network changes.

## 6.2 Date/Time

By clicking on the **System > Date/Time** of the PRI Gateway menu, we reach this section:

**Configuration Type :** Date and Time of the PRI Gateway can be either set manually (uses RTC) or automatically (through NTP). Default: **NTP**

**Manual Configuration :** Enter the proper date and time.

**NTP Configuration :**

**Time Zone:** Select the correct time zone for the location where the PRI Gateway is installed using the Time Zone dropdown box. Default: **Asia/Kolkata**

**NTP Server:** URI or IP address of the NTP (Network Time Protocol) server, which will be used to synchronize the date and time. E.g.: 3.in.pool.ntp.org

### Date/Time Configuration ?

Configuration Type:

Manual Configuration	NTP Configuration
Date: <input type="text" value="21"/> / <input type="text" value="07"/> / <input type="text" value="2014"/> (dd/mm/yyyy) Time: <input type="text" value="08"/> : <input type="text" value="59"/> (hh:mm)	Timezone: <input type="text" value="Asia/Kolkata"/> NTP Server: <input type="text" value="3.in.pool.ntp.org"/> <input type="button" value="Add"/> <input type="text" value="192.168.0.8"/> <input type="button" value="Delete"/>

Figure 37: Date/Time Configuration

Click on **“APPLY”** button, followed by **“SAVE ALL”** button to update the configuration changes.



Figure 38: Conform

 Changing the configuration requires the current calls to be disconnected.

# Tools


## 7. Tools

This chapter consists of various tools which are used in the PRI Gateway are explained below.

### 7.1 Diagnostics

It analyze the functionality of the PRI Gateway with some of these diagnostic tools provided.

Navigate through **Tools > Diagnostics** of the PRI Gateway menu, we reach the below section



The screenshot shows the 'Diagnostics' section of the PRI Gateway interface. It features two main panels: 'Ping Test' and 'Traceroute Test'. Both panels have a 'Host' input field containing '192.168.0.135'. The 'Ping Test' panel has a 'Count' dropdown menu set to '1' and a 'Ping' button. The 'Traceroute Test' panel has a 'Hops' dropdown menu set to '3' and a 'Traceroute' button. The interface is clean and uses a blue and white color scheme.

Figure 39: Diagnostics

**Ping Test:** It is used to check the packet loss and latency time from your SIP end client like IP Phone/ FXS gateways to check the quality of your network connections.

Enter the IP address of the IP Phone in your LAN and enter “PING” Button, it will display similar to like this:




Figure 40: Diagnostics Ping Result

**Trace route Test:** It is used to determine the route taken by packets across an IP network.

## 7.2 Backup/Restore

Navigation: **TOOLS > Backup/Restore:** Here you can back up or Restore the PRI Gateway Configurations.

1. **Backup Configuration:** Allows you to create a backup of the existing Configuration and Voice files of the PRI Gateway
2. **Restore Configuration:** Allows you to upload a backup file to the PRI Gateway, which is restored instantly




Figure 41: Backup & Restore



Administrator password will not be restored on restoration. So you should still use same credentials as before restoration.

### 7.3 Upgrade Firmware

Navigate through **Tools > Upgrade Firmware**




Figure 42: Upgrade Firmware

The Firmware Upgrade page allows you to update the PRI Gateway with the latest release available, which can contain key updates, added functionalities and bug fixes. When a new release is available, download it and save to your local PC.

Then, browse for the file, and click the Upload button.

Now your PRI Gateway will display a Progress Screen and will prompt you when your PRI Gateway is about to reboot.

Let your PRI Gateway reboot, and wait for the Blue LED's to come back on.

Click on upgrade button.



During firmware upgrade, there should not be any power or network disturbances, which may leads to PRI Gateway board faulty. Firmware up-gradation process will take few minutes.

# Status


## 8. Status

This section generates the various status of the PRI Gateway are explained below.

### 8.1 Call Reports

Navigate through **STATUS > CALL REPORTS**

Call Reports displays a detailed list of calls pass through the PRI Gateway. The list can be generated on the bases of date range, CDR count, latest 50 entries or all entries. Generated report can also be exported to local PC as CSV file or directed to a printer.



Call Reports ?

Generate Type:  Generate Export Print

Show  entries Search:

No. ^	Start Time	Caller	Callee	Duration	Status	Owner	Hangup Cause	Link ID
1	2014-07-18 15:16:51	4542	5858	4	Answered	4542	Normal Cleaning	1405676811.116
2	2014-07-18 15:16:41	5858	4542	0	Failed	5858	Call Cancelled	1405676798.114
3	2014-07-18 15:16:03	5858	4542	5	Answered	5858	Normal Cleaning	1405676760.112
4	2014-07-18 15:08:10	5858	4542	17	Answered	5858	Normal Cleaning	1405676286.110
5	2014-07-18	4542	5858	15	Answered	4542	Normal	1405676258.108

Showing 1 to 10 of 50 entries First Previous 1 2 3 4 5 Next Last

Figure 43: Call Reports

To create a new Report, select the Extension Range or Date range, and click the “**Generate**” Report button. A list with call details will display in the Call Reports section.

You can either export to your local PC or Print the Call reports.

**Start time:** The time at which something is supposed to begin

**Caller:** Source Number (It displays the name and telephone number of a caller, which appear on a display as the call is being received.)

**Callee:** Destination Number (the person who is called by the caller)

**Duration:** It calculates the conversation time of a call.

**Status:** It shows the status of the call like answered or failed.

**Hangup cause:** The reason of call disconnection.

**Link ID:** It is associated with a particular conversation.

## 8.2 SIP Trunks

Navigation : **STATUS > SIP TRUNKS** this is where you find the status of SIP Trunk Status.

SIP Trunk Status page displays detailed status of each SIP trunks available on the PRI Gateway.

## SIP Trunks Status ?

No.	Ac. Name	Username	Host	Dynamic	Port	Status	Reg. State
1	1333	1333	(Unspecified)	D	5060	UNKNOWN	
2	2016	2016	192.168.0.130		5161	OK	Request Sent
3	5111	5111	(Unspecified)	D	5060	UNKNOWN	
4	IPPHONE	6001	(Unspecified)	D	5060	UNKNOWN	
5	IPPHONE2	6002	(Unspecified)	D	5060	UNKNOWN	
6	OPENSER	8942	192.168.0.100		5060	OK	

Showing 1 to 6 of 6 entries

First Previous 1 Next Last

Figure 44: SIP Trunk Status

SIP Trunk Status page displays detailed status of each SIP trunks available on the PRI Gateway.

Status	Reg. State	Description	
OK	Registered	Configured, Registered & reachable	-
OK	-	Configured & Reachable, but no Registration	-
OK	Request Sent	Configured, but Host not responding or unreachable	Check Registrar Address
OK	Rejected	Configured & reachable, but Registration failure	Check Authentication
UNREACHABLE	Registered	Configured, Registered, but not reachable	Check Proxy Address
UNREACHABLE	-	Configured, but not reachable	Check Proxy Address

UNKNOWN	-	Not Registered	Client not registered
---------	---	----------------	-----------------------

Dynamic: Host IP is obtained dynamically on registration.

### 8.3 PRI Span

Navigate through **Status > PRI Span**




Figure 45: PRI Span Status

PRI Span Status page displays detailed status of each E1/T1 Port with individual channel info, available on the PRI Gateway.



If you click on the Plus symbol, you will get the PRI Span details.

Below you can see the status of the E1/T1 Port and Channel Status.

E1/T1 Port	Description
Status	

	Appliance is not seeing far end, circuit is not up, or cable is bad.
	Appliance is synchronizing or is receiving a yellow alarm from the far end.
	PRI Link is Active. Appliance is in-sync with the far end.
	T1/E1 driver is not initialized or device undetected.

Channel Status	Description
	Channel is Busy
	Channel is Idle and ready to receive or make calls
	Channel is not active

## 8.4 Current calls

Navigate through **Status > Current Calls**

Current Calls page displays detailed status of the real time calls available on PRI Gateway.

The following screenshot you can find the active calls




Figure 46: Current calls

## 8.5 Network

Navigate through **Status > Network**

Network Status page displays detailed status of the network configuration on PRI Gateway.

**Network Status:** This is where you can find the LAN and WAN IP address and MAC Addresses.




Figure 47: Network Status

# FAQs

## 9. Frequently Asked Questions

### 1. How to find the IP address of PRI Gateway?

Follow the below steps

Connect a RJ45 cable from LAN port of the G/W to your PC directly.

Set the PC network configuration as 192.168.113.xxx series

Connect WAN port of G/W to your network switch

Open 192.168.113.2 in a browser.

Homepage will show you the WAN IP address of the device

Access the G/W using the WAN IP from your network.

### 2. What are all the different ways you can connect PRI gateway with IPPBX?

“Add SIP trunk” tab in PRI gateway provides you three modes of connection, which creates the connection between gateway and IPPBX

Registration Mode is “From Gateway”: Gateway is sending registration request to the IPPBX or any VoIP service provider.

Registration Mode is “To Gateway”: Gateway is receiving registration request from any IPPBX (as a SIP trunk in IPPBX)

Registration Mode is “None”: It’s an IP PEER trunk between gateway and IPPBX.

### 3. Did routing is available in PRI Gateway?

Call is coming from PRI trunk and going to IPPBX via SIP trunk

Calling Number – 9769657470

Called Number (DID) - 80203500 to 80203600 (PRI line Numbers)

Select” Incoming from” –PRI

Pattern as-X,

Trim Digits-4

When call goes out of gateways via SIP trunk

Calling Number-9769657470

Called Number- 3500 to 3600

#### **4. What are all the call routing rules is available for different routing pattern configuration?**

Incoming type: Source of the call, from where the call is coming in the gateway.

1) If you want to accept incoming call which has only 4 digits dialed, then write pattern as XXXX (X is form 0 to 9)

2) If you want to accept incoming call with any number of digits, then write X. (. is wild card which accepts any length of number)

3) If dialed number is 65654008, and if you want to prepend 99 to dialed number, then put 99 in prepend field and dialed number when it reaches destination trunk will be 9965654008.

4) If dialed number is 65654008, and if you want to strip 2 digits from the dialed number, then put 2 in trim digits field and dialed number when it reached destination trunk will be 654008

#### **5. Why Ring back is not coming for the call?**

When you are making a call it has got connected but there is no ring back. Follow the below steps:

Open GUI and Navigate through ISDN PRI Settings.

Click Advanced in PRI Settings at the right corner of the page.

A pop up page will open with “Edit PRI Advanced Settings”. Check that box with “Enable progress indication”.

Click Save or Save All, Gateway will reboot.

# Appendix

## 10. Appendix

### Pin Assignments:

All RJ45 (8P8C) ports labeled T1/E1 on the Gateway Series appliance are 8-pin. RJ45 jacks are also commonly referred to as RJ48 when used for telecommunication. The pin assignments are identified in below table.

	Pin	Description
	1	Rx Ring
	2	Rx Tip
	3	Unused
	4	Tx Ring
	5	Tx Tip
	6	Unused
	7	Unused
	8	Unused

PRI CROSS OVER CABLE




Figure 48: PRI Cross over cable

# Glossary

## 11. Appendix B: Glossary and Acronyms

Term	Definition
<b>DS0 Digital Signal</b>	Level 0 a voice grade channel of 64 kbps. The worldwide standard speed for digitizing voice conversation is used by PCM (Pulse Code Modulation).
<b>DTMF</b>	<i>Dual Tone Multi-Frequency</i> Push-button or touch tone dialing.
<b>E1</b>	The European equivalent of North American T1, transmits data at 2.048 Mbps, up to 32 channels (DS0s).
<b>E3</b>	The European equivalent of North American T3, transmits data at 34.368 Mbps, up to 512 channels (DS0s). Equivalent to 16 E1 lines
<b>EMI</b>	<i>Electromagnetic Interference</i> Unwanted electrical noise.
<b>Full duplex</b>	Data transmission in two directions simultaneously.
<b>FXS</b>	<i>Foreign Exchange Station</i> Initiates and sends ringing voltage and Phones are connected to FXS ports.
<b>G.711</b>	A recommendation by the Telecommunication Standardization Sector (ITU-T) for an algorithm designed to transmit and receive ulaw PCM voice and A-law at a digital bit rate of 64 kbps.
<b>G.723.1</b>	A recommendation by the Telecommunication Standardization Sector (ITU-T) for an algorithm designed to transmit and receive audio at 6.3 kbps or 5.3 kbps.
<b>G.729a</b>	A recommendation by the Telecommunication Standardization Sector (ITU-T) for an algorithm designed to transmit and receive audio at 8 Kbps
<b>HDLC</b> <i>High-Level</i>	A bit-oriented synchronous data link layer protocol developed by the

Term	Definition
<i>Data Link Control</i>	International Organization for Standardization (ISO).
<b>ILBC</b> <i>internet Low Bit rate Codec</i>	A free speech codec used for voice over IP. It is designed for narrow band speech with a payload bit rate of 13.33 kbps (frame length = 30ms) and 15.2 kbps (frame length = 20ms).
<b>PBX</b> <i>Private Branch Exchange</i>	A smaller version of a phone is a company's large central switching office. Example: Asterisk.
<b>POTS</b> <i>Plain Old Telephone Service</i>	The public switched telephone network (PSTN) is the network of the world's public circuit-switched telephone networks. Originally a network of fixed-line analog telephone systems, the PSTN is now almost entirely digital, and now includes mobile as well as fixed telephones.
<b>PPP</b> <i>Point-to-Point Protocol</i>	Type of communications link that connects a single device to another single device, such as a remote terminal to a host computer.
<b>PRI</b>	Primary Rate ISDN
<b>PSTN</b> <i>Public Switched Telephone Network</i>	A communications network use telephones to establish connections between two points. Also referred to as the dial network.
<b>PTMP</b> <i>Point-to-Multipoint</i>	A connection where data is broadcast between more than two endpoints.
<b>RJ11</b>	A six-pin jack typically used for connecting telephones, modems, and fax machines in residential and business settings to PBX or the local telephone CO.
<b>RJ45</b>	8P8C, un-keyed modular connector type for Ethernet over twisted pair. Predominantly used in LAN and uses Unshielded Twisted Pair cable.
<b>RJ48</b>	8P8C modular connector type for T1 and ISDN termination over twisted pair. While RJ45 and RJ48 use the same connector, they differ in their wiring. RJ48

Term	Definition
	is commonly seen on T1 lines and uses Shielded Twisted Pair cable.
<b>SIP</b> <i>Session Initiation Protocol</i>	An IETF standard for setting up sessions between one or more clients. It is currently the leading signaling protocol for Voice over IP, gradually replacing H.323.
<b>T1</b>	A dedicated digital carrier facility which transmits up to 24 voice channels (DS0s) and transmits data at 1.544 Mbps. Commonly used to carry traffic to and from private business networks and ISPs.
<b>VoIP</b> <i>Voice over Internet Protocol</i>	Technology used for transmitting voice traffic over a data network using the Internet Protocol.

#### EXPERIENCING THE ALLO PRI Gateways:

Please visit our website: <http://allo.com> to receive the most up- to-date updates on firmware releases, additional features, FAQs, documentation and news on new products.

If you have purchased our products through an ALLO Certified Partner or Reseller, please contact them directly for immediate support.

Our technical support Engineers are ready to answer all of your queries. Kindly submit a [trouble ticket online](#) to receive in-depth support.

\* *Asterisk is a Registered Trademark of Digium, Inc.*

Thank you for choosing



Adarsh Eco Place, #176, Ground Floor, EPIP Industrial Area, Kundalahalli  
KR Puram Hobali, Whitefield, Bangalore - 560066.

Email: [globalsales@allo.com](mailto:globalsales@allo.com)  
[indiasales@allo.com](mailto:indiasales@allo.com)

Phone: +91 80 67080808